



MONT75 Series

Elevator Integrated Controller

Starting Guide



V1.0 2020.12

MONT75 Series Elevator Integrated Controller Starting Guide

Thank you for using MONT75 Elevator Integrated Controller manufactured by Shenzhen Hpmont Technology Co., Ltd.

Version and Revision Records

Time: 2020/12

Version: V1.0

Revised	Revised Contents
	• V1.0 publish

CONTENTS

1. MONT75 System Introduction	1
1.1 Controlling System Configuration	1
1.2 Main Control Board (MT90-MCB-A)	2
1.3 Terminal Description	3
1.4 Indicator Description	4
1.5 Jumper Description	5
1.6 Small Keypad Description	6

2. Simple Debugging and Application	12
2.1 Adjustment Process	12
2.2 Check Wiring	12
2.3 Set Parameter	13
2.4 Motor Auto-tuning	15
2.5 Machine Room Inspection Operation	16
2.6 Shaft Self-learning	18
2.7 Check before High Speed	19
2.8 High Speed Running	22
2.9 Adjustment for Comfortable Feeling	24
2.9.1 Adjust Starting Confort Performance	24
2.9.2 Adjusting Running Confort Performance	26
2.9.3 Adjust Running Curve	28
2.9.4 Adjust End Station Confort Performance	28
2.9.5 Adjust Parking Confort Performance	30
2.9.6 Leveling Accuracy Adjustment	31
2.9.7 Adjust All Levelings	31
2.9.8 Fine-tune Every Leveling	32
2.9.9 Test New Elevator Fatigue	32

2.10 UCMP Function.....33
2.11 Brake Force Detection Function34
2.12 Over Load and Full Load Description35

3. Faults and Countermeasures.....36
3.1 Fault Sort Explanation36
3.2 Fault Code Description36
3.3 Processing Failure37
3.4 Reset Fault50

1. MONT75 System Introduction

1.1 Controlling System Configuration




Figure 1-1 MONT75 controlling system configuration

1.2 Main Control Board (MT90-MCB-A)

The main control board (MT90-MCB-A) is the core of the control system and using the industry leading 32-bit DSP as the control core, which completes high-performance traction machine vector control, communicates with CTB (car top board), HCB (hall call board) and GCB (group control board), and achieves signal I/O processing and elevator logic control.




Figure 1-2 MT90-MCB-A

1.3 Terminal Description

Table 1-1 Terminal description

Terminal		Description
X1 - X24, X29 - X32	Digital input	Total 24 groups, programmable bipolar optional optocoupler-isolated input signals <ul style="list-style-type: none"> • Input voltage: 0 - 30VDC • Input impedance: 4.7kΩ • The function is set by F12.01 - F12.24
X25 - X28, XCM_H	High voltage input terminal	Optocoupler-isolated input signals <ul style="list-style-type: none"> • Input voltage: 110 - 220VAC/DC • Input impedance: 22kΩ • The function is set by F12.25 - F12.27
AI, GND	Analogue input	Input voltage range: -10 - +10V; Input impedance: 34k Ω
Y1 - Y7, CM1 - CM7	Relay contact NO output	Programmable output <ul style="list-style-type: none"> • Y1 - Y3 contact capacity: 250VAC/3A or 30VDC/1A • Y4 - Y7 contact capacity: 250VAC/3A or 30VDC/1A • The function is set by F12.28 - F12.33
+24V, COM	+24V power supply	External DC 24V power input, as I/O circuits and communication circuit power
MOD1+, MOD1-	Modbus communication	For Modbus communicating with HCB (MT70-HCB-*) <ul style="list-style-type: none"> • Recommended to use shielded twisted pair
MOD2+, MOD2-	Modbus communication	For Modbus communicating with IoT module (MT70-CIC-*) <ul style="list-style-type: none"> • Recommended to use shielded twisted pair
CAN1+, CAN1-	CAN communication	For CAN communicating with CTB (MT70-CTB-A) <ul style="list-style-type: none"> • Recommended to use shielded twisted pair
CAN2+, CAN2-	CAN communication	For CAN communicating with GCB (MT70-GCB-A), or with MCB which is in parallel <ul style="list-style-type: none"> • Recommended to use shielded twisted pair
CAN3+, CAN3-	CAN communication	For CAN communicating with power regenerative unit
GND	CAN3 communication ground	
CN3	RJ45	Modbus communication terminals, extensional keypads <ul style="list-style-type: none"> • Check or modify MCB parameter
CN11	USB interface	Connect Bluetooth module (MT70-BLE-A)
+12V, COM	+12V power supply	Emergency power input





1.4 Indicator Description

Table 1-2 Indicator description

Indicator		Description
RUN	Elevator operation indicator	<ul style="list-style-type: none"> Flashing at run Lighting at stop
COP	CTB CAN communication indicator	<ul style="list-style-type: none"> Flashing at normal communication Extinguishing at abnormal
GROUP	GCB CAN communication indicator	<ul style="list-style-type: none"> Flashing at normal communication Extinguishing at abnormal
HOP	HCB Modbus communication indicator	<ul style="list-style-type: none"> Flashing at normal communication Extinguishing at abnormal
Safe	Safety circuit indicator	<ul style="list-style-type: none"> Lighting at safety circuit closing Extinguishing at disconnection
LOCK	Locked-door circuit indicator	<ul style="list-style-type: none"> Lighting at locked-door circuit closing Extinguishing at disconnection
INS	Inspection indicator	<ul style="list-style-type: none"> Lighting at elevator inspection state Extinguishing at other states
Error	Fault indicator	<ul style="list-style-type: none"> Lighting at serious fault, flashing at general fault Extinguishing at no fault
MOD2	IoT module communication indicator	<ul style="list-style-type: none"> Flashing at normal communication Extinguishing at abnormal
CAN3	Power regenerative unit CAN communication indicator	<ul style="list-style-type: none"> Flashing at normal communication Extinguishing at abnormal

1.5 Jumper Description

Table 1-3 Jumper descriptions

Jumper		Descriptions
J3		<p>At connecting MT70-GCB-A or two elevators in parallel, CAN2 communication resistor selection can be set:</p> <ul style="list-style-type: none"> • Pin1&2 are short-connected, no matching resistor (factory setting). • Pin2&3 are short-connected, with matching resistor.
J4		<p>At connecting IoT module. Modbus 2 communication resistor selection can be set:</p> <ul style="list-style-type: none"> • Pin1&2 are short-connected, no matching resistor (factory setting). • Pin2&3 are short-connected, with matching resistor.
J5		<p>At connecting power regenerative unit, CAN3 communication resistor selection can be set:</p> <ul style="list-style-type: none"> • Pin1&2 are short-connected, no matching resistor (factory setting). • Pin2&3 are short-connected, with matching resistor.
CN2		<p>Digital input terminal X1 - X24 are high level/low level selections:</p> <ul style="list-style-type: none"> • Pin 1&2 are short-connected, the low level is valid; • Pin 2&3 are short-connected, the high level is valid (factory setting).

1.6 Small Keypad Description

Keypad Description




Figure 1-3 Keypad key

Table 1-4 Keypad key description

Key	Description
PRG	<ul style="list-style-type: none"> At any state, pressing PRG key can display the present function group number.
UP	<ul style="list-style-type: none"> At function group number menu, via UP key to increase group number which can be changed cyclically. At specific functional data menu, you can also input simple command.
SET	<ul style="list-style-type: none"> At function group number menu, pressing SET key can enter data menu of this function group. At data menu, after input simple command, press SET key to save, and then enter into data menu display of F0.

Display Function

The keypad displays the information about the MCB, and input simple command.

Make functions in group F0 - F17, as shown in Table 1-5. See Table 1-6 for detailed function.

Table 1-5 Small keypad display function group




Keypad Display Function		
F0: Floor and run direction information	F6: Display present date	F12: Elevator running direction modify
F1: Call command input	F7: Shaft self-learning command input	F13: History fault
F2: Fault reset	F8: Test function	F14: Manual detection of brake force
F3: Carrier frequency	F9: OD and CD control	F15: UCMP start test
F4: Encoder direction	F10: Parameter auto-tuning	F16: Check hall call address
F5: Display run times	F11: Car top IO status inquiry	F17: Communicaiton parameter restore factory parameters

Table 1-6 Small keypad display description

Function	Description																												
F0: Floor and run direction information	<p>After power on, the digital tube defaults to display the data of group F0 (floor and direction).</p> <ul style="list-style-type: none"> • The first digital tube displays the current elevator direction. • Flashes when running, and does not light up when stopped. • The last two digital tubes display the current elevator floor. • Flashes when running, and always on when stopping. <p>When the system fault occurred (there is no fault before), the fault code and the data of group F0 are displayed alternately.</p> <ul style="list-style-type: none"> • If the fault disappears automatically, the data of F0 will be displayed. <p>During system shaft self-learning, when E50 occurs, "E50" and "bxx" will be displayed alternately.</p> <ul style="list-style-type: none"> • E50: Shaft self-learning failure. • xx: Fault subcode, meaning see the table below. <table border="1" data-bbox="325 592 1005 1382"> <thead> <tr> <th data-bbox="330 599 404 625">bxx</th> <th data-bbox="407 599 1001 625">Meaning</th> </tr> </thead> <tbody> <tr> <td data-bbox="330 636 404 689">b01</td> <td data-bbox="407 636 1001 689">When the upper limit switch is activated, the current floor is not the highest floor</td> </tr> <tr> <td data-bbox="330 694 404 756">b02</td> <td data-bbox="407 694 1001 756">After the completion of shaft self-learning, the upper limit switch is not action</td> </tr> <tr> <td data-bbox="330 760 404 791">b03</td> <td data-bbox="407 760 1001 791">When starting self-learning, the current running direction is down</td> </tr> <tr> <td data-bbox="330 796 404 826">b04</td> <td data-bbox="407 796 1001 826">Start self-learning, the next forced slowdown switch is not action</td> </tr> <tr> <td data-bbox="330 831 404 862">b05</td> <td data-bbox="407 831 1001 862">Start self-learning, the current floor is not the first floor</td> </tr> <tr> <td data-bbox="330 867 404 928">b06</td> <td data-bbox="407 867 1001 928">Starting the self-learning, the current control mode (F00.01) is not closed loop vector control</td> </tr> <tr> <td data-bbox="330 933 404 994">b07</td> <td data-bbox="407 933 1001 994">When the current floor is the highest level, the up forced Dec. switch 1 is not actuated</td> </tr> <tr> <td data-bbox="330 999 404 1061">b08</td> <td data-bbox="407 999 1001 1061">After self-learning, F19.13 (the down forced Dec. switch 1 distance) is 0</td> </tr> <tr> <td data-bbox="330 1065 404 1127">b09</td> <td data-bbox="407 1065 1001 1127">After self-learning, F19.12 (the up forced Dec. switch 1 distance) is 0</td> </tr> <tr> <td data-bbox="330 1131 404 1193">b10</td> <td data-bbox="407 1131 1001 1193">After self-learning, F19.15 (the down forced Dec. switch 2 distance) is 0</td> </tr> <tr> <td data-bbox="330 1198 404 1259">b11</td> <td data-bbox="407 1198 1001 1259">After self-learning, F19.14 (the up forced Dec. switch 2 distance) is 0</td> </tr> <tr> <td data-bbox="330 1264 404 1325">b12</td> <td data-bbox="407 1264 1001 1325">After self-learning, F19.17 (the down forced Dec. switch 3 distance) is 0</td> </tr> <tr> <td data-bbox="330 1330 404 1392">b13</td> <td data-bbox="407 1330 1001 1392">After self-learning, F19.16 (the up forced Dec. switch 3 distance) is 0</td> </tr> </tbody> </table>	bxx	Meaning	b01	When the upper limit switch is activated, the current floor is not the highest floor	b02	After the completion of shaft self-learning, the upper limit switch is not action	b03	When starting self-learning, the current running direction is down	b04	Start self-learning, the next forced slowdown switch is not action	b05	Start self-learning, the current floor is not the first floor	b06	Starting the self-learning, the current control mode (F00.01) is not closed loop vector control	b07	When the current floor is the highest level, the up forced Dec. switch 1 is not actuated	b08	After self-learning, F19.13 (the down forced Dec. switch 1 distance) is 0	b09	After self-learning, F19.12 (the up forced Dec. switch 1 distance) is 0	b10	After self-learning, F19.15 (the down forced Dec. switch 2 distance) is 0	b11	After self-learning, F19.14 (the up forced Dec. switch 2 distance) is 0	b12	After self-learning, F19.17 (the down forced Dec. switch 3 distance) is 0	b13	After self-learning, F19.16 (the up forced Dec. switch 3 distance) is 0
bxx	Meaning																												
b01	When the upper limit switch is activated, the current floor is not the highest floor																												
b02	After the completion of shaft self-learning, the upper limit switch is not action																												
b03	When starting self-learning, the current running direction is down																												
b04	Start self-learning, the next forced slowdown switch is not action																												
b05	Start self-learning, the current floor is not the first floor																												
b06	Starting the self-learning, the current control mode (F00.01) is not closed loop vector control																												
b07	When the current floor is the highest level, the up forced Dec. switch 1 is not actuated																												
b08	After self-learning, F19.13 (the down forced Dec. switch 1 distance) is 0																												
b09	After self-learning, F19.12 (the up forced Dec. switch 1 distance) is 0																												
b10	After self-learning, F19.15 (the down forced Dec. switch 2 distance) is 0																												
b11	After self-learning, F19.14 (the up forced Dec. switch 2 distance) is 0																												
b12	After self-learning, F19.17 (the down forced Dec. switch 3 distance) is 0																												
b13	After self-learning, F19.16 (the up forced Dec. switch 3 distance) is 0																												

Function	Description																																						
	<table border="1" data-bbox="311 186 967 1159"> <thead> <tr> <th data-bbox="311 186 393 220">bx</th> <th data-bbox="393 186 967 220">Meaning</th> </tr> </thead> <tbody> <tr> <td data-bbox="311 220 393 289">b14</td> <td data-bbox="393 220 967 289">After self-learning, the down forced Dec. switch 2 is lower than the down forced Dec. switch 1</td> </tr> <tr> <td data-bbox="311 289 393 358">b15</td> <td data-bbox="393 289 967 358">After self-learning, the up forced Dec. switch 2 is higher than the up forced Dec. switch 1</td> </tr> <tr> <td data-bbox="311 358 393 428">b16</td> <td data-bbox="393 358 967 428">After self-learning, the down forced Dec. switch 3 is lower than the down forced Dec. switch 2</td> </tr> <tr> <td data-bbox="311 428 393 497">b17</td> <td data-bbox="393 428 967 497">After self-learning, the up forced Dec. switch 3 is higher than the up forced Dec. switch 2</td> </tr> <tr> <td data-bbox="311 497 393 551">b18</td> <td data-bbox="393 497 967 551">The up forced switch is effective, the elevator leveling zone, the current floor is not the highest floor</td> </tr> <tr> <td data-bbox="311 551 393 620">b19</td> <td data-bbox="393 551 967 620">After self-learning, D06.08 (the distance of the leveling plate) is more than 50cm</td> </tr> <tr> <td data-bbox="311 620 393 651">b20</td> <td data-bbox="393 620 967 651">Self-learning data overflow 1</td> </tr> <tr> <td data-bbox="311 651 393 682">b21</td> <td data-bbox="393 651 967 682">Self-learning data overflow 2</td> </tr> <tr> <td data-bbox="311 682 393 713">b22</td> <td data-bbox="393 682 967 713">Total height of floors is less than 50cm</td> </tr> <tr> <td data-bbox="311 713 393 743">b23</td> <td data-bbox="393 713 967 743">During self-learning, cancel the inspection command</td> </tr> <tr> <td data-bbox="311 743 393 813">b24</td> <td data-bbox="393 743 967 813">During self-learning, the permanent magnet synchronous motor does not perform angle self-learning</td> </tr> <tr> <td data-bbox="311 813 393 913">b25</td> <td data-bbox="393 813 967 913">Two floors, starting self-learning, down leveling switch is in inserting board (normally should be under leveling inserting board)</td> </tr> <tr> <td data-bbox="311 913 393 944">b26</td> <td data-bbox="393 913 967 944">When starting self-learning, the upper limit switch is active</td> </tr> <tr> <td data-bbox="311 944 393 974">b27</td> <td data-bbox="393 944 967 974">When start self-learning, the up forced Dec. switch is active</td> </tr> <tr> <td data-bbox="311 974 393 1044">b28</td> <td data-bbox="393 974 967 1044">Distance of down forced Dec. switch is higher than the up forced Dec. switch</td> </tr> <tr> <td data-bbox="311 1044 393 1074">b29</td> <td data-bbox="393 1044 967 1074">Down forced Dec. switch adhesion</td> </tr> <tr> <td data-bbox="311 1074 393 1105">b30</td> <td data-bbox="393 1074 967 1105">Up leveling switch adhesion</td> </tr> <tr> <td data-bbox="311 1105 393 1159">b31</td> <td data-bbox="393 1105 967 1159">Down leveling switch adhesion</td> </tr> </tbody> </table> <p data-bbox="281 1182 990 1295">The system is in the inspection state and no fault. When the keypad displays the data of group F0, press and hold the UP and SET key at the same time. After more than 3s, the shaft self-learning will be carried out directly, which is equivalent to the keypad F07 = 1.</p>	bx	Meaning	b14	After self-learning, the down forced Dec. switch 2 is lower than the down forced Dec. switch 1	b15	After self-learning, the up forced Dec. switch 2 is higher than the up forced Dec. switch 1	b16	After self-learning, the down forced Dec. switch 3 is lower than the down forced Dec. switch 2	b17	After self-learning, the up forced Dec. switch 3 is higher than the up forced Dec. switch 2	b18	The up forced switch is effective, the elevator leveling zone, the current floor is not the highest floor	b19	After self-learning, D06.08 (the distance of the leveling plate) is more than 50cm	b20	Self-learning data overflow 1	b21	Self-learning data overflow 2	b22	Total height of floors is less than 50cm	b23	During self-learning, cancel the inspection command	b24	During self-learning, the permanent magnet synchronous motor does not perform angle self-learning	b25	Two floors, starting self-learning, down leveling switch is in inserting board (normally should be under leveling inserting board)	b26	When starting self-learning, the upper limit switch is active	b27	When start self-learning, the up forced Dec. switch is active	b28	Distance of down forced Dec. switch is higher than the up forced Dec. switch	b29	Down forced Dec. switch adhesion	b30	Up leveling switch adhesion	b31	Down leveling switch adhesion
bx	Meaning																																						
b14	After self-learning, the down forced Dec. switch 2 is lower than the down forced Dec. switch 1																																						
b15	After self-learning, the up forced Dec. switch 2 is higher than the up forced Dec. switch 1																																						
b16	After self-learning, the down forced Dec. switch 3 is lower than the down forced Dec. switch 2																																						
b17	After self-learning, the up forced Dec. switch 3 is higher than the up forced Dec. switch 2																																						
b18	The up forced switch is effective, the elevator leveling zone, the current floor is not the highest floor																																						
b19	After self-learning, D06.08 (the distance of the leveling plate) is more than 50cm																																						
b20	Self-learning data overflow 1																																						
b21	Self-learning data overflow 2																																						
b22	Total height of floors is less than 50cm																																						
b23	During self-learning, cancel the inspection command																																						
b24	During self-learning, the permanent magnet synchronous motor does not perform angle self-learning																																						
b25	Two floors, starting self-learning, down leveling switch is in inserting board (normally should be under leveling inserting board)																																						
b26	When starting self-learning, the upper limit switch is active																																						
b27	When start self-learning, the up forced Dec. switch is active																																						
b28	Distance of down forced Dec. switch is higher than the up forced Dec. switch																																						
b29	Down forced Dec. switch adhesion																																						
b30	Up leveling switch adhesion																																						
b31	Down leveling switch adhesion																																						
F1: Call command input	<p data-bbox="281 1305 818 1329">After enter group F1, digital tube displays "1" (physical floor).</p> <ul data-bbox="281 1336 897 1390" style="list-style-type: none"> • Press the UP key to set the destination floor, range [1 - Max. floor]. • After pressing the SET key, the data of group F0 is displayed. 																																						

Function	Description
F2: Fault reset	After enter group F2, digital tube displays "0". <ul style="list-style-type: none"> Press the UP key to set to 1, the range [0,1]. After pressing the SET key, the current system fault will be cleared, and "F3" will be displayed after completion.
F3: Carrier frequency	After enter group F3, digital tube displays actual carrier frequency (F18.00). <ul style="list-style-type: none"> In inspection mode, you can press the UP key to set the range [4 - 8]. After pressing the SET key, "F4" is displayed.
F4: Encoder direction	After enter group F4, digital tube displays actual encoder direction (F11.02). <ul style="list-style-type: none"> In inspection mode, you can press the UP key to set the range [0,1]. After pressing the SET key, "F5" is displayed. Need to set F27.26 Bit6 = 1 (allow the keypad to modify the encoder direction).
F5: Display run times	After enter group F5, digital tube cyclically displays the run times. <ul style="list-style-type: none"> Move to the left to cycle the display, after the display is over, restart the cycle from the highest digit. Display up to 999,999 times.
F6: Display present date	After enter group F6, digital tubes cyclically display the time, such as "2012-08-21-14-30".
F7: Shaft self-learning command input	After enter group F7, digital tubes display "0". <ul style="list-style-type: none"> Then press UP key to set and the range is [0 - 2]. <ul style="list-style-type: none"> 1: Start shaft self-learning (do not clear F27.01 - F27.25), 2: Start shaft self-learning (clear F27.01 - F27.25). After pressing the SET key, when the self-learning conditions are met, the elevator starts self-learning, and displays the data of group F0. After the self-learning is completed, the data of group F7 returns to 0.
F8: Test function	After enter group F8, digital tubes display "00". <ul style="list-style-type: none"> Press UP key to set, range [00 - 05]. <ul style="list-style-type: none"> 00: No function. 01: Block hall call. 02: Block the door open. 03: Block overload. 04: Block the limit switch. 05: Allow the elevator to run 500 times randomly. After pressing SET key, digital tubes are flashing to display "E88", which means the present setting of the elevator is at testing state. After pressing the PRG key, the data in group F8 returns to 0.
F9: OD and CD control	After enter group F9, digital tube displays "1-1". <ul style="list-style-type: none"> Press the UP key to open the door, press the SET key to close the door, and press the PRG key to exit.

Function	Description															
<p>F10: Parameter auto-tuning</p>	<p>After entering group F10, the digital tube displays "0".</p> <ul style="list-style-type: none"> In the inspection state or the keypad state, press the UP key to set, the range is [0 - 2]. <ul style="list-style-type: none"> 1: Static auto-tuning. 2: Rotating auto-tuning. After pressing the SET key, the digital tube flashes "TnE", wait for 2s to confirm that the elevator meets the operating conditions, and then press the SET key to perform parameter auto-tuning. <ul style="list-style-type: none"> Syn. motor, the value of F10.12 (initial angle of Syn. motor) will be displayed after completion. This value is displayed cyclically when it is larger than 99.9°, and displayed directly when it is smaller than 99.9°. After 3s, "F0" is displayed. Asyn. motor, the value of F07.11 (Asyn. motor no-load current) will be displayed after completion. This value is displayed cyclically when it is larger than 99.9A, and displayed directly when it is smaller than 99.9A. After 3s, "F0" is displayed. During auto-tuning, press PRG key to stop. Need to set F27.26 Bit5 = 1 (allow the keypad auto-tuning). <p><i>Note:</i></p> <ol style="list-style-type: none"> For static Auto-tuning of permanent magnet syn. motor, it needs the inspection condition and given the direction of the signal, the tuning process can be referred to section 2.4. For static auto-tuning of Asyn. motor, it does not need the above conditions. 															
<p>F11: Car top IO status inquiry</p>	<p>After entering group F11, the digital tube displays the input status of the terminal.</p> <ul style="list-style-type: none"> No.1 (left): Car top board. No.2 (middle): Car command board of main car operation panel. No.3 (right): Car command board of vice car operation panel. <p>The corresponding terminals of the digital tube segment are shown in the table below.</p> <ul style="list-style-type: none"> When the digital tube segment lights up, the corresponding terminal has a signal input. <table border="1" data-bbox="311 1087 969 1322"> <thead> <tr> <th data-bbox="311 1087 519 1121">Digital Tube Mark</th> <th colspan="2" data-bbox="519 1087 969 1121">Digital Tube Corresponding Terminal</th> </tr> </thead> <tbody> <tr> <td data-bbox="311 1121 519 1171">  </td> <td data-bbox="519 1121 731 1171">A: X1 terminal</td> <td data-bbox="731 1121 969 1171">E: X5 terminal</td> </tr> <tr> <td></td> <td data-bbox="519 1171 731 1222">B: X2 terminal</td> <td data-bbox="731 1171 969 1222">F: X6 terminal</td> </tr> <tr> <td></td> <td data-bbox="519 1222 731 1273">C: X3 terminal</td> <td data-bbox="731 1222 969 1273">G: X7 terminal</td> </tr> <tr> <td></td> <td data-bbox="519 1273 731 1322">D: X4 terminal</td> <td data-bbox="731 1273 969 1322">DP: X8 terminal</td> </tr> </tbody> </table>	Digital Tube Mark	Digital Tube Corresponding Terminal			A: X1 terminal	E: X5 terminal		B: X2 terminal	F: X6 terminal		C: X3 terminal	G: X7 terminal		D: X4 terminal	DP: X8 terminal
Digital Tube Mark	Digital Tube Corresponding Terminal															
	A: X1 terminal	E: X5 terminal														
	B: X2 terminal	F: X6 terminal														
	C: X3 terminal	G: X7 terminal														
	D: X4 terminal	DP: X8 terminal														
<p>F12: Elevator running</p>	<p>After entering the group F12, the digital tube shows the actual elevator running direction (F00.10).</p>															

Function	Description
direction modifying	<ul style="list-style-type: none"> In the inspection mode, press the UP key to set, the range is [0,1], and "F0" will be displayed after completion. Need to set F27.27 Bit15 = 1 (allow to modify the elevator running direction). After modification, the shaft self-learning needs to be performed again, otherwise it cannot high speed run.
F13: History fault	<p>After entering the F13 group, the digital tube flashes "-01" "EXX" "-02" "EXX", until "-10" "EXX".</p> <ul style="list-style-type: none"> "-01" is the first fault, "EXX" is the fault code, and "E00" is displayed without fault. 10 historical fault messages can be displayed.
F14: Brake force manual detection	<p>In elevator automatic mode, after entering group F14, the digital tube displays "0".</p> <ul style="list-style-type: none"> Press the UP key to set it to 1, and after pressing the SET key the brake force detection is started. If the brake is detected successfully, the value of F04.17 is automatically increased by 1. If the brake detection fails, the system reports E66 (brake force self-detection failure), and the fault can only be reset manually in the inspection mode.
F15: UCMP start test	<p>After entering group F15, the digital tube displays "0".</p> <ul style="list-style-type: none"> Press the UP key to set to 1, and press the SET key to turn on the UCMP test function.
F16: Hall call address verificaiton	<p>After entering group F16, the digital tube displays "0".</p> <ul style="list-style-type: none"> Press the UP key to set it to 1, after pressing the SET key, the HCB board enters the address verification mode when the MCB board and the HCB board communicate normally. External up and down call signals set the hall call address. After setting, modify the data of F16 to "0".
F17: Recover communication parameter to default	<p>After entering group F17, the digital tube displays "0".</p> <ul style="list-style-type: none"> Press the UP key to set to 1, and press the SET key to restore the factory values of F14.00 and F14.01.

2. Simple Debugging and Application

Introduce the basic steps of designing the system and the method of setting parameters when MONT75 constitutes the elevator control system.

2.1 Adjustment Process

After the mechanical installation and wiring are completed, it is recommended to debug MONT75 according to the following steps.

1.	Check, section 2.2, page 12
2.	Set Parameter , section 2.3, page 13
3.	Motor Auto-tuning, section 2.4, page 15
4.	Machine Room Inspection Operation, section 2.5, page 16
5.	Shaft Self-learning, section 2.6, page 18
6.	Check before High Speed, section 2.7, page 19
7.	High Speed Running, section 2.8, page 22
8.	Adjustment for Comfortable Feeling, section 2.9, page 24
9.	UCMP Function, section 2.10, page 33
10.	Brake Force Detection Function, section 2.11, page 34

Note:

When debugging, it is recommended that more than two people work at the same time.

When abnormal conditions occur, immediately cut off the power supply.

2.2 Check Wiring

1.	Refer to the manual to confirm that all parts are connected correctly.
2.	Confirm that the hoistway is unblocked, no passenger in the car, and the elevator has the conditions for safe operation.
3.	Check the wiring of the input power supply and the motor to confirm that the wiring is correct.
4.	Confirm that the following are reliably grounded to ensure personal safety. <ul style="list-style-type: none"> • Control panel. • Motor. • Car ground wire. • Hall door ground wire.
5.	Confirm that there is no short circuit. <ul style="list-style-type: none"> • If there is a short circuit, remove it before powering on.

2.3 Set Parameter

1.	Restore the factory parameter: Set F01.02 = 1, pree ENT key.
2.	Set the parameters according to the actual situation, see the table below. After setting the parameters, press the ENT key to set successfully. You can view the status of the input and output terminals on the MCB board and the CTB board through group D.

Ref. Code	Function	Recommended	Remark
F00.00	Motor type	Based on the actual setting	
F00.01	Control mode	2 (VC control)	
F00.02	Elevator Max. running speed	Based on the actual setting	
F00.03	Elevator rated speed		
F00.04	Elevator rated load		
F00.05	Controller Max. output frequency		Generally set as the motor rated frequency
F03	Acc. and Dec. curve parameter	Set in needing	
F04	Speed parameter	Set in needing	
F07.00	Asyn. motor rated power	Based on the actual setting	Set according to the value on the nameplate of the Asyn. motor
F07.01	Asyn. motor rated voltage		
F07.02	Asyn. motor rated current		
F07.03	Asyn. motor rated frequency		
F07.04	Asyn. motor rated Rpm		
F07.05	Asyn. Motor power factor		
F10.01	Syn. motor rated power	Based on the actual setting	Set according to the value on the nameplate of the Syn. Motor <i>Note: If F10.00, F10.06 - F10.09 have no accurate parameters, please set it to 0, otherwise the elevator may not run normally</i>
F10.02	Syn. motor rated voltage		
F10.03	Syn. motor rated current		
F10.04	Syn. motor rated frequency		
F10.05	Syn. motor rated Rpm		
F10.09	Syn. Motor counter emf		

Ref. Code	Function	Recommended	Remark
F11.00	Encoder card selection	Based on the actual setting	Setting by encoder
F11.01	Encoder pulses/rotation		
F11.02	Encoder rotation direction setting		
Group F12	MCB input terminal setting	Set according to the drawings	Jumper CN2 selects inputting high or low level is valid. Set normally open, normally closed input by parameter. Observe the LED lights corresponding to the input terminals to determine the input status. X25 - X27 are high voltage safety circuit, door lock circuit input. To ensure safety, please ensure that the safety circuit and door lock circuit are correct. F26.14 Bit4 sets X28 rear door high voltage door lock short circuit input.
	MCB relay output setting	Set according to the drawings	Observe the corresponding LED lights of the relay to confirm the relay output status.
Group F13	CTB input terminal setting	Set according to the drawings	Observe the LED lights corresponding to the input terminals to confirm the input status.
	CTB relay output terminal setting	Set according to the drawings	Observe the corresponding LED lights of the relay to confirm the relay output status.
Group F23	Time parameters	Based on the actual setting	Confirm that F23.03 - F23.08 match the actual situation. • If not, please reset.

2.4 Motor Auto-tuning

Asyn. Motor Auto-tuning

1.	Set F00.07 = 0 (keypad control).
2.	<p>Static auto-tuning: Set F07.06 = 1 (static auto-tuning), press RUN key on the keypad to start auto-tuning.</p> <ul style="list-style-type: none"> • Automatically open the run contactor. • The motor will make a howling sound for about 30s. • The motor rotates slowly once. <p>Rotary auto-tuning: Set F07.06 = 2 (rotary auto-tuning), press the RUN key on the keypad to start auto-tuning.</p> <ul style="list-style-type: none"> • The brake contactor needs to be opened manually. • The motor rotates. • If the motor vibration or overcurrent occurs, press the STOP key to terminate, adjust F07.21 and F07.22 (suppress vibration).
3.	After finishing the auto-tuning, set F00.07 = 1 (distance control).

Syn. Motor - Static Auto-tuning

1.	Confirm that the door lock circuit and the safety circuit is connected.
2.	<p>Set F10.12 = 0 (Syn. motor initial angle), F00.07 = 1 (distance control), F10.10 = 1 (static angle auto-tuning).</p> <ul style="list-style-type: none"> • If the system is equipped with a Syn. shorting motor stator contactor, please set the related parameters of shorting motor stator contactor and run contactor. • When auto-tuning, the system will automatically control the shorting motor stator contactor. Otherwise, the output may be short-circuited, and an overcurrent fault may be reported.
3.	<p>Give the inspection and direction signals, the elevator will do inspection running and start auto-tuning.</p> <ul style="list-style-type: none"> • The controller sends out a series of pulse voltages, and the motor buzzes. • After the buzzing sound is over, the motor starts inspection running, and it stops automatically after turned a circle.
4.	<p>Check the parameter value, and record F10.12 (not 0).</p> <ul style="list-style-type: none"> • ABZ/UVW encoder: Get F10.12, indicating that the auto-tuning is correct. • SINCOS encoder: Get F10.14 - F10.17 and F10.12, which means that the auto-tuning is correct.
5.	<p>Repeat the auto-tuning twice (steps 3 - 4), record F10.12, and subtract the three values in pairs.</p> <ul style="list-style-type: none"> • ABZ/UVW encoder: The difference is within 30°, otherwise it needs to be re-tuned. • SINCOS encoder: The difference is within 5°, or within 5° of 360° / integral multiple of the number of pole pairs of the motor, otherwise it needs to be re-tuned.
6.	Remove inspection and direction commands.

Note:
<p>1. The given direction is inconsistent with the actual running direction. Measures to be taken: Reverse the value of F00.10 (elevator running direction), and perform auto-tuning again.</p>
<p>2. During auto-tuning, when the motor is just from standstill to starting, it reports E0030 (encoder reverse) or E0031 (encoder disconnection). Measures to be taken: Change the encoder direction (F11.02), it is still invalid, try to reduce the speed loop KP, KI (group F08).</p>
<p>3. During the auto-tuning process, if there is a fault such as overcurrent or encoder reverse, it may be that the encoder direction is reversed. Measures to be taken: Set F11.02 = 1 (reverse the encoder direction), and perform auto-tuning again.</p>
<p>4. Unsuccessful auto-tuning may cause a risk of motor overspeed. It is recommended that two people cooperate (one presses the INS button, the other presses the emergency stop button). When motor overspeed occurs, press the emergency stop button to switch the power supply.</p>
<p>5. When an abnormality occurs during auto-tuning, press the emergency stop button to stop auto-tuning.</p>

2.5 Machine Room Inspection Running

1. Confirm that the door lock circuit and the safety circuit is connected.
<p>2. According to the actual situation to set F03.06 (inspection running Acc. speed), F04.00 (inspection running speed), F26.12 (inspection parameter setting).</p> <ul style="list-style-type: none"> • For the first inspection run, set a lower inspection speed.
<p>3. Give inspection and direction signals, and the elevator will start inspection running (or slow running). If the elevator can run and the motor runs in the correct direction, it will succeed.</p>
<p>4. Check the up and down leveling switches and door zone signals to confirm the correct sequence:</p> <ul style="list-style-type: none"> • When do up inspection running, the effective signals are in order: Up leveling signal, door zone signal, down leveling signal. • When do down inspection running, the effective signals are in order: Down leveling signal, door zone signal, up leveling signal. <p>If the sequence is wrong, please check the external wiring.</p>

Note:	
1.	<p>The running direction of the traction motor is incorrect.</p> <p>Measures to be taken: Check the up and down input terminals wiring and parameter settings, if the wiring is correct, set F00.10 = 1 (elevator running direction).</p>
2.	<p>During elevator inspection running, the feedback speed of the motor displayed by MONT75 is unstable or has a large deviation from the given value.</p> <p>Measures to be taken: Check the wiring between the encoder and the encoder card.</p> <ul style="list-style-type: none"> • Make sure that the connecting wire used is correct. If the encoder is a differential signal, a shielded twisted pair cable should be used; If not, can use general shielded cables. • Make sure that the wiring is reasonable. The encoder connection cable and the power cable must be strictly separated, and can not run in the same wire slot. • Check the grounding of the shielding wire and shielding net is reliable.
3.	<p>For Asyn. motor, the system reports E0030 (encoder reverse) during inspection running.</p> <p>Measures to be taken: Encoder AB direction may be misconnected, change F11.02 (encoder direction).</p>
4.	<p>For Syn. motor, such as SINCOS encoders, error or motor overspeed occur during inspection running.</p> <p>Measures to be taken: Check the CD wiring of the SINCOS encoder, confirm that it is correct.</p>
5.	<p>During inspection running, if the hoistway related switches are not installed in place, the system may report a fault.</p> <p>Measures to be taken: Set F26.12 (inspection parameter setting) to shield the fault.</p>
6.	<p>In many cases, the slow running of the machine room is not an inspection running, but an emergency electric running.</p> <p>During running, the safety circuit switch is shorted, and special attention must be paid. The switches include: Safety gear switch, governor switch, up overspeed protection switch, uplimit and downlimit switches, buffer reset switch.</p> <p>Suggestion: The running time and distance should not be too long, and don't run the car to the terminal.</p>

2.6 Shaft Self-learning

1.	Set F19.00 (total floor).
2.	Give inspection and direction signals.
3.	Run the elevator to the downlimit position and confirm: <ul style="list-style-type: none"> • The down forced Dec. signal is valid, and the corresponding indicator on the MCB board is on. • The current floor is the first floor, which is displayed on keypad. <ul style="list-style-type: none"> • When the total floor is 2, make sure that the down leveling switch is below the leveling plate. • When the total floor is greater than 2, there must be at least one leveling switch in the leveling plate.
4.	Perform any of the following operations to start shaft self-learning: <ul style="list-style-type: none"> • Keypad set F26.01 = 1. • Small keypad set F7 = 1. • When the small keypad displays the data of group F0, press and hold the UP and SET keys at the same time for 3s.
5.	The elevator runs at the self-learning speed (F04.03), and records the length of the leveling plate, the height of each floor, and the position of the up and down forced Dec. switch.
6.	The elevator stops automatically when it reaches the uplimit, and the system has no faults, the self-learning is completed.
7.	Confirm self-learning data: <ul style="list-style-type: none"> • The system automatically calculates the elevator running speed curve according to the elevator floor distance, and stores it in F19.07 - F19.11 (the curve is the highest speed). Generally, no modification is required. • Check F19.12 - F19.17 to confirm the forced Dec. position is correct. • Check the group F20 to confirm that the floor data is correct. • Check D04.02 (shortest floor distance), D04.03 (highest floor distance), make sure it matches the actual situation. • Check D06.06 (number of leveling switches), D06.07 (length between leveling switches), D06.08 (length of leveling plate), make sure it matches the actual situation.
Note:	
1.	In any of the following situations, shaft self-learning must be performed again: <ul style="list-style-type: none"> • Adjust the position of the leveling plate. • Adjust the position of the forced deceleration switch. • Modify F00.10 (elevator running direction).
2.	Self-learning is interrupted, system reports E50 (shaft self-learning failure). Measures to be taken: Refer to section 3.3 to clear the fault, and restart the shaft self-learning.

2.7 Check before High Speed

Check the System Communication

1.	The CAN1+ and CAN- communication terminals of MCB SK3 terminal are respectively connected to the CAN+ and CAN- communication terminals of CTB. The MOD+ and MOD- communication terminals of MCB's SK3 terminal are respectively connected to the MOD+ and MOD- communication terminals of HCB.
2.	When the system is powered off manually, measure the impedance between CAN1+ and CAN1-, which should be 60Ω. <ul style="list-style-type: none"> If there is a short circuit, please eliminate it; If the impedance is wrong, please check the selection switch of the terminal resistance of each board.
3.	Power on, confirm that the communication is normal, and the indicators on the MCB board flash evenly. <ul style="list-style-type: none"> COP: Communication status between MCB and CTB board. HOP: Communication status between MCB and HCB board.

Set Hall and Car Board Address

The hall call address settings are shown in the table below.

The car call address is set to 0, and the setting method is the same as that of the hall call board.

Set by Button (MT70-HCB-H, MT70-HCB-F, MT70-HCB-U1)	
1.	Press and hold the SW button on the back of the HCB board, and release it when the HCB board flashes to display the floor.
2.	After 3s, when the display does not flash, press the up or down button to set the target floor address.
3.	Press the SW button or wait for 5s, the HCB board flashes again to display the floor, it means the setting is successful.
4.	After 3s, HCB board displays normally.
Set by Jumper (MT70-HCB-I)	
1.	Short-circuit the jumper on the front of the HCB board, and remove the short-wire when the HCB board flashes to display the floor.
2.	When the display is not flashing, press the up/down button to set the target floor address. <ul style="list-style-type: none"> For single elevator, the floor address is the actual physical floor; for parallel group control, please refer to the MONT75 user manual.
3.	Wait for 5s, the HCB board flashes again to display the floor, it means the setting is successful.
4.	After 3s, HCB board displays normally.

Set by Parameter (MCB ver. V1.07 and above, HCB ver. V1.6 and above)	
1.	Set the MCB board F26.31 = 1 (the HCB board displays the hall call address).
2.	The HCB board direction displays "T", when the floor displays the current HCB board address, press and hold the up and down buttons at the same time for 3s, or press the up or down button alone for 6s until the HCB board direction is empty and the floor is flashing displayed.
3.	After 3s, when the display does not flash, press the up or down button to set the target floor address.
4.	Wait for 5s, the HCB board flashes again to display the floor, it means the setting is successful.
5.	After 3s, HCB board displays the hall call verification address.
Note:	
1.	<ul style="list-style-type: none"> • For single elevator, the floor address is the actual physical floor. • In parallel group control, if the bottom position of the elevator is inconsistent, please refer to the MONT75 user manual. • When there is opposite door, please refer to the MONT75 user manual.

Through group D parameters, you can view car and hall call elevator signals, communication status, communication interference and other signals, see the table below.

Ref. Code	Function
D04.00	Present floor
D04.01	Present height
D04.02	Distance of lowest floor
D04.03	Distance of highest floor
D04.04	Registration state of 16 - 1 car call floor
D04.05	Registration state of 32 - 17 car call floor
D04.06	Registration state of 48 - 33 car call floor
D04.07	Registration state of 16 - 1 hall call up
D04.08	Registration state of 32 - 17 hall call up
D04.09	Registration state of 48 - 33 hall call up
D04.10	Registration state of 16 - 1 hall call down
D04.11	Registration state of 32 - 17 hall call down
D04.12	Registration state of 48 - 33 hall call down
D04.13	HCB communication state of 16 - 1
D04.14	HCB communication state of 32 - 17
D04.15	HCB communication state of 48 - 33
D04.16	Car communication state display

Ref. Code	Function
D04.17	Hall call Modbus communication interference evaluation
D04.18	Car top CAN communication interference evaluation
D04.19	Parallel CAN communication interference evaluation

Debug Open and Close Door

1.	The elevator is under inspection.
2.	Set the door controller parameters to ensure that the door controller has a normal operating curve, and can normally output the door open and close signal.
3.	The door open and close signal of the door controller is connected to the control system.
4.	The operation command input terminal of the door controller is connected to the door open and door close output terminals of the CTB board.
5.	The elevator does inspection running to the leveling area.
6.	Do any of the following operations to give the door open and close command: <ul style="list-style-type: none"> • Press and hold the up and down inspection button at the same time to open the door; press and hold the up or down inspection button alone to close the door. • Long press the RUN key on the keypad to open the door, and the STOP key to close the door. • Press the open button of the car operation panel to open the door, and the close button to close the door.
7.	Confirm that the door machine is running in the correct direction, the door opening and closing signal is normal, and the light curtain and touch plate signal are valid. <ul style="list-style-type: none"> • View D05.00 and D05.01 on the keypad, monitor the door machine opening and closing door in place, light curtain, safety touch plate and other signals. • In the inspection mode, the light curtain and safety touch plate activated, and the door is not opened, but the signal can be monitored.
Note:	
1.	The keypad can be connected to the RJ45 port of MCB, CTB, CCB for debugging.

2.8 High Speed Running

Confirm before Running

1.	The safety circuit is connected.
2.	Door lock circuits are connected.
3.	The system doesn't have level 2 or 3 faults, and overload signal input.
4.	Door controller CD arrival signal is valid.
5.	Floor storey data is correct.
6.	When the motor is synchronous, F10.12 (initial angle of the Syn. motor) is not 0.
7.	The inspection running is normal, and the shaft self-learning is successful.

High Speed Commissioning

1.	The inspection switch is set to normal, and the elevator is in a normal state.
2.	Use the keypad to set F26.00 (floor of car call), and perform automatic operation of single, double, multi-floor and total floor respectively. Set F26.00, which is equivalent to registering car call floor command.
3.	Confirm that the elevator can open and close doors, accelerate and decelerate, call the elevator, and stop normally.

Safe Test Running

Safety Circuit Test	
1.	When the elevator is on standby, the safety circuit is disconnected, the elevator cannot run, and the system reports E0041 (safety circuit disconnection).
2.	When the elevator is running, the safety circuit is disconnected, the elevator stops in an emergency, and the system reports E0041.
3.	After the door lock circuit is connected, the fault can be automatically reset.
Door Lock Circuit Test	
1.	At the elevator standby, and the door lock circuit is disconnected, the elevator can not run.
2.	At the elevator running, and the door lock circuit is disconnected, the elevator emergency stop and the system alarms E0042 fault (door locked disconnection during running).
3.	After the door lock circuit is closed, the fault is automatically reset.

Contactors Adhesion Protection Test

1. For run contactors, brake contactors, synchronous star-closed contactors, door-closed contactors and other artificial adhesion situations, check that the system can report fault when above situation occurs.
 - E0056: Run contactor feedback abnormality.
 - E0057: Brake contactor feedback abnormality.
 - E0054: Synchronous star-closed contactor feedback abnormality.
 - E0047: Door-closed contactor feedback abnormality.

Over-load Function Test

1. The elevator overload switch action, check the elevator is not closed, buzzer inside the car, car call board with overload display.

2.9 Adjustment for Comfortable Feeling

2.9.1 Adjust Starting Confort Performance

Phenomenon and Adjustment				
Phenomenon				
There is a starting jerk in car when the elevator starts.				
Adjustment				
Possible Cause	Detection Method	Processing Measures	Remark	
Parameter setting problem	Pre-torque is not turned on	Check whether the parameter, settings are reasonable	Set parameter related with pretorque	1
	Brake open slowly	whether the elevator starts with the brake	Check brake open time and increase F02.01	
	Brake not open fully	Observe opening clearance	Adjust gap	2
Guide shoe is too tight, static friction force is too big	Try shaking the car and feel the gap between guides	Adjust guide shoe clearance, add guide rail oil or adjust speed loop PI	3	
Remark				
1. How to set pre-torque parameter?				
For brake itself, the opening time is different, while the brake response time is affected by the ambient temperature (too high brake coil temperature will cause the brake delayed response), the appropriate increase in curve run delay time F02.01. The pre-torque parameter is set below:				
Ref. Code	Function	Setting Range	Default	Remark
F02.01	Curve running delay time	0.000 – 2.000s	0.500s	Elevator brake opened and then after F02.01 time, to run again
F05.00	Start pretorque selection	0: No pretorque 1: Analogue weighing 2: Digital weighing 3: Pretorque autocompensation	0	Select the pretorque according to requirement • Generally set to 3
F05.16	No weighing current coefficient	0 - 9999	3000	Slipping in starting, increase F05.16 - F05.18 • Overlarge value will cause oscillation
F05.17	No weighing speed loop KP	1 - 9999	1000	
F05.18	No weighing speed loop KI	1 - 9999	1000	

2. The problem of brake interval

- Confirm the brake can open, brake force is enough and brake coil loop is connected.
- Make sure that the brake opening clearance is sufficient. If the brake is fricting, adjust the brake clearance.
- Make sure that the brakes on both sides is synchronized, if not synchronized, please adjust it into the synchronization.
- If the brake opening sound is too loud, please make the sound small.

3. Guide shoe is too tight, static friction is too large

- Ensure whether the guide shoe is too tight, if too tight, adjust the guide shoe.
- Adjust starting speed or speed loop PI to overcome the static friction, the parameters are as follows.

Ref. Code	Function	Setting	Default	Remark
F02.02	Starting speed	0.000 - 0.030s	0.000 m/s	Initial speed of system startup <ul style="list-style-type: none"> • Proper starting speed can overcome static friction
F02.03	Start speed holding time	0.000 - 2.000s	0.000s	Holding time of starting speed
F02.06	Start ramp time	0.000 - 2.000s	0.000s	The time required for the elevator to accelerate from zero speed to elevator rated speed (F00.03) <ul style="list-style-type: none"> • Use with F02.02
F08.00	Low speed loop KP	1 - 9999	500	Increase the PI parameter to increase the dynamic response of the system <ul style="list-style-type: none"> • Overlarge value will cause oscillation
F08.01	Low speed loop KI	1 - 9999	500	

2.9.2 Adjusting Running Confort Performance

Phenomenon and Adjustment			
Phenomenon			
Up and down vibration during Acc. and Dec. or constant speed.			
Adjustment			
Possible Cause	Detection Method	Processing Measures	Remark
The guide shoe is too tight and the friction is too large	Judge the vibration time by F02.01 (curve running delay time): the moment of brake opening or the beginning of the curve	Adjust the gap between the guide shoe and the guide rail to reduce friction; increase the starting speed	1
Mechanical rotating parts problem	Check whether there is periodic vibration	Adjust or replace mechanical parts	Bearing
Guide rail problem	Shake left and right when running, or shake relative to a fixed position	Adjust the guide rail or polish the joints	The guide rail is not level, there are foreign matters, and the interface is not flat
System control (acceleration, deceleration, constant speed vibration)	Whether there is periodic vibration, the PI parameter value is too small	Adjust PI parameters	2
Resonance during operation	uring operation, the buzzing resonance in the car	Check mechanical problems or adjust PI parameters	

Remark**1. Judge the vibration time: Start slipping, or curve operation at the beginning.**

Set F02.01 to the maximum, and the elevator will run at speed after the brake has opened for F02.01.

- Vibration when starting to open the brakes and slipping: After vibration, the elevator's zero speed will remain stable within F02.01, and then start running.
- Vibration at the beginning of the S-curve: The brake is opened, the elevator stops, and the vibration occurs again after waiting for F02.01.

2. System control issues

Vibration during acceleration, deceleration or constant speed, adjust PI parameters as follows:

Ref. Code	Function	Setting	Default	Remark
F08.00	Low speed loop KP	1 - 9999	500	For vibration when the frequency is lower than frequency 1, increase F08.00/F08.01
F08.01	Low speed loop KI	1 - 9999	500	
F08.02	High speed loop KP	1 - 9999	500	
F08.03	High speed loop KI	1 - 9999	500	For vibration when the frequency is higher than frequency 2, increase F08.02/F08.03
F08.04	Speed loop PI switching frequency 1	0.00 - 50.00 Hz	10.00Hz	For vibration when the frequency is between frequency 1 and frequency 2, take the average of the low-speed PI and high-speed PI • Excessive adjustment on parameter may cause oscillation
F08.05	Speed loop PI switching frequency 2	0.00 - 50.00 Hz	15.00Hz	
F09.00	Current loop KP	1 - 4000	500	Increase the current loop KP and KI appropriately to reduce vibration • Excessive adjustment may cause system overcurrent
F09.01	Current loop KI	1 - 4000	500	

Note: If F10.20 bit15 = 1 (enable vibration suppression function), adjust F09.04 (loop parameter) and F18.00 (carrier frequency) to avoid the mechanical resonance point.

2.9.3 Adjust Running Curve

Phenomenon and Adjustment
<p>Phenomenon</p> <p>MONT75 adopts S-curve Acc. and Dec., which minimizes the impact during Acc. and Dec., and makes the start and stop smoother.</p> <p>However, different applications require different Acc. and Dec. curve parameters.</p> <p>Too fast Acc. and Dec. affects the confort performance, and too slow Acc. and Dec. reduce the operating efficiency of the elevator.</p> <p>Adjustment</p> <p>Please adjust the value of the parameter F03.00 - F03.05 when the Acc./Dec. is slow, otherwise increase the value of parameter F03.00 - F03.05.</p> <ul style="list-style-type: none"> • Acc. (F03.01, F03.02): Rate of Acc. • Dec. (F03.04, F03.05): Rate of Dec. • Rapid Acc (F03.01, F03.02): The rate of change of Acc. • Rapid Dec (F03.04, F03.05): The rate of change of Dec.

2.9.4 Adjust End Station Confort Performance

Phenomenon and Adjustment			
<p>Phenomenon</p> <p>The elevator is running to the position of forced Dec. switch, the rapid speed to the leveling area in crawl speed.</p> <p>Adjustment</p>			
Possible Cause	Detection Method	Processing Measures	Remark
Forced Dec. switch problem	Check whether the switch action is normal	Replace the switch	
	Check whether the circuit is normal	Wiring	
Forced Dec. switch distance problem	Check the forced Dec. switch installation distance	Adjust the installation distance	1
Rope slips	Check rope slip	Adjust the mechanical part	2
Incorrect mechanical parameter setting	Check whether the mechanical parameter (F00.06) is Acc.urate	mechanical parameters as well as the actual mechanical parameters	

Remark													
<p>1. Installation distance</p> <p>The installation distance between the forced deceleration switch and the leveling position of the end station is S, and the calculation formula is:</p> $S > \frac{V^2}{2 \times F03.12}$													
Rated speed (m/s)	0.25	0.4	0.5	0.75	1	1.5	1.6	1.75	2	2.5	3	3.5	4
First-level forced Dec. distance (m)	0.4	0.4	0.4	0.4	0.7	1.4	1.5	1.8	2	2	2	2	2
Secondary forced Dec. distance (m)	No	No	No	No	No	No	No	No	2.5	4	4	4	4
Third forced Dec. distance (m)	No	No	No	No	No	No	No	No	No	No	6	8	11
<p>2. Rope slips</p> <p>Step 1: Confirm that there is no oil leakage from the rope. If yes, wipe dry with a cloth</p> <p>Step 2: Confirm that the wrap angle of the rope and the traction sheave is set reasonably.</p> <p>Step 3: Confirm that the elevator balance system is correct. If it is not correct, make it correct first, generally between 0.4 - 0.5.</p>													

2.9.5 Adjust Parking Confort Performance

Phenomenon and Adjustment			
Phenomenon			
There is a jerk in the car when the elevator going to park in leveling area.			
Adjustment			
Possible Cause	Detection Method	Processing Measures	Remark
The door lock is disconnected at the moment of parking	Check the gap between the door cam and the croquet	Adjust the gap	
System error	Check error	Solve error	
Speed loop PI cannot track	Increase PI parameters	Increase F08.00 and F08.01 appropriately	Increase the PI parameter, the system will respond faster, if the parameter is increased too much, oscillation may occur
Brake open too slowly	Adjust the brake force	Adjust the braking force, there is no resistance to open the brake	
	Cancel freewheeling delay	Ensure that the brake contactor is connected and immediately disconnect the brake force supply	
	Observe whether there is a car slipping when parking		1
Remark			
1. Why increase the stop zero speed hold time			
As the brake coil is powered for a long time, slow brake releasing is caused by heat, after running contactor release (the system does not output torque), the brake has not been fully closed, resulting in slipping, there is a jerk in car.			
At this time, need to increase the torque output when stopping, that is, increase the stop zero speed hold time F02.05.			



2.9.6 Leveling Accuracy Adjustment

Phenomenon and Adjustment	
<p>Phenomenon</p> <p>When the elevator stops and car door opens, the car leveling is not consistent with the hall leveling. If the car leveling is higher than the hall leveling, it is higher-leveling, If the car leveling is lower than the hall leveling, it is less-leveling.</p> <p>Adjustment</p> <ol style="list-style-type: none"> 1. Ensure that installation of the leveling plate is Acc.urate. And the length of each leveling plate should be the same. 2. Ensure there is no overadjustment in system running, speed loop parameters (group F08) have influence on leveling accuracy. 3. Ensure encoder signal works well. If the encoder gets interferences, the leveling accuracy will be affected. 4. When the elevator runs normally, adjusting leveling accuracy methods is as following form. 	
<p>F19.06 = 0 Direct stop mode 0</p>	<p>Set F19.03 (leveling distance adjustment) to tine-tuning.</p> <ul style="list-style-type: none"> • When elevator stops, higher-leveling decreases F19.03, less-leveling increases F19.03.
<p>F19.06 = 1 Direct stop mod 1</p>	<p>Ensure elevator has a short ascend (ascend distance is set by F19.03), set F03.13 (parking emergency Dec) and F04.02 (asending speed) to fine-tuning.</p> <ul style="list-style-type: none"> • When elevator stops, higher-leveling increses by F03.13; less-leveling decreaseF03.13. • F03.13 no need to modify generally, after shaftway self-learning F03.13 will upgrade automatically to ensure the leveling accuracy.

2.9.7 Adjust All Levelings

Adjustment (MCB ver. V1.10 and above)	
F03.17 = 0	F19.03 fine-tune all the up levelings and down leveling.
F03.17 = 1	F03.15 fine-tune all the up levelings, F03.16 fine-tune all the down leveling.

2.9.8 Fine-tune Every Leveling

Adjustment	
F27.01 = 0	<p>F27.02 - F27.25 per parameter can adjust 2 floors.</p> <ul style="list-style-type: none"> • Can fine-tune 48 floors. <p>Adjust methods (take the F27.02 as an example):</p> <ul style="list-style-type: none"> • Far left 2 numbers adjust floor 1, far right 2 numbers adjust floor 2. • The Max. adjust range is 0 - 60mm, the default value is 30mm. • Less-leveling increase value (30), higher-leveling decrease value (30). <div style="text-align: right;">  <p>Floor 1 Floor 2</p> </div>
F27.01 = 1	<p>F27.02 - F27.25 per parameter can adjust 1 floor.</p> <ul style="list-style-type: none"> • Can fine-tune 24 floors. <p>Adjust methods (take the F27.02 as an example):</p> <ul style="list-style-type: none"> • Far left 2 numbers fine-tune the up leveling of floor 1, far right 2 numbers fine-tune down leveling of floor 1. • The max adjust range is 0 - 60mm, the default value is 30mm. • Less-leveling increase value (30), higher-leveling decrease value (30). <div style="text-align: right;">  <p>Up Down</p> </div>

2.9.9 Test New Elevator Fatigue

Test New Elevator Fatigue
<p>After the new elevator installed, need to have a run-in test on new elevator.</p> <p>Set group F25 parameter, test the random operation time, and the fixed operation method of the floor.</p>

2.10 UCMP Function

Description

When lock-door contactor outputs, controller detects that the door zone signal got invalid from valid, and door lock signal disconnected, system alarms E65 (UCMP fault), elevator stops running, lock-door contactor stops outputing.

When elevator stops, controller detects that the door zone signal got invalid from valid, door lock signal disconnects, and any leveling signal invalid, system alarms E65 (UCMP fault), elevator stops running.

Test Step

1.	Make sure detect switch valid, elevator stops at door zone, keep closed status.
2.	Switch to inspection status.
3.	Open UCMP test function, by any operation below: <ul style="list-style-type: none"> • Small keypad set F15 = 1. • Keypad set F25.04 Bit7 = 1.
4.	Disconnect system door lock signal (manual switch, control panel adds one door lock disconnect switch).
5.	Press inspection up or down button manually, lock-door contactor outputs, door lock shortcircuit, elevator starts, normal inspection running.
6.	After that elevator runs off door zone, UCMP module disconnect door lock shortcircuit, system alarms E65 (UCMP fault), elevator stops running
Additional remarks:	
1.	Not in the inspection state, door zone and door lock closed, with keypad set F15 = 1 invalid.
2.	With small keypad set F15 = 1, auto resetting after running once or power-off.
3.	During test, system as 0.8m/s^2 accelerate automatically (no need to set), to ensure the average accelerated speed is greater than 0.5m/s^2 .

Reset E65 Fault

E65 fault can not reset automatically, reset by executing any operation below:

- In the inspection state, reset automatically.
- When F16.05 Bit10 = 1, reset by power-off (not recommended).

2.11 Brake Force Detection Function

Description

Detection software is HpmontBrakeMonitor, software version is V1.00 (D06.48).

Parameter Setting

Ref. Code	Name	Setting Range	Recommended
F03.18	Brake force detection method	0: invalid 1: Manual start detection 2: Automatic start detection	Syn. motor 2 Asyn. motor 0
F03.19	Brake force detection cycle	1 - 15 day	1
F03.20	Brake force detection time point	00:00 - 23:59	3:00
F04.14	Brake detection duration	1 - 10s	5s
F04.15	Brake detection torque	60 - 150%	100%
F04.16	Brake detection allows pulse size	1 - 99	5
F04.17	Brake detection success times	0 - 65535	0

Note: F03.19 takes the time of the clock chip in the main board as reference. When control system do not set brake mechanical switch detection F03.19 is 1 day.

Detection Method

- When the elevator is in the automatic state, the safety circuit is normal and the door lock circuit is closed.
 - Automatic detection**

Enable the brake force auto-detection function: set F03.18 = 2.

When reaches to detection period and detection time, after elevator response to COP and LOP calling signal stop at leveling zone, running contactor outputs, enable brake force auto-detection.

Manual detection

Enable manual-detection function: set F03.18 = 1 or F25.04 Bit8 = 1 or small keypad F14 = 1.

After elevator response to COP and LOP calling signal stop at leveling zone, running contactor outputs, enable brake force auto-detection

Manual inspection under inspection state

Start the manual detection function: set F03.18 = 1 or F25.04 Bit8 = 1.

Press both down and com or up and com button in control panel, running contactor outputs, enable brake force auto-detection.
 - The running contactor stops and the brake force detection ends.
 - Confirm that F04.17plus 1 based on origin value, indicates the brake force detection success.
- If alarm E66fault, indicates, F04.17 do not change.

Reset E66 Fault

Excute any operation below to reset:

- **Do the brake force auto-detection again:** Set F17.07 Bit3 = 0, in auto mode, do the brake force auto-detection again, until pass the test.
- **Inspection manual reset once:** Set F17.07 Bit3 = 1, in inspection state, kaypad return to fault interface, press **STOP** key. F17.07 Bit3 can auto-resettig.
- **Power off and power on to reset:** Set F16.05 Bit10 = 1, power off, and power on.

2.12 Over Load and Full Load Description

MONT75 provide various over load, full load signal input methods.

Digital input terminal input

- Set MCB or CTB input terminal as over load or full load input, can set NO or NC.
- Can only set either of MCB or CTB digital input, if set two, the two will conflict.

Analog weighing signal input

- MCB AI terminal, set F05.01 = 3; CTB AI terminal, set F05.01 = 2.
- If exceeds 80% of the full load signal, think it full load; exceeds 110%, think it over load.

Note:

Digital value can be used together with Analog value weighing.

3. Faults and Countermeasures

3.1 Fault Sort Explanation

MONT75 has almost 70 pieces of protection functions.

MONT75 monitors every running condition all the time, once error occurs, protection function acts, displays fault code.

Error information produced by MONT75 can be divided into 4 sorts according to their influence to the system. Different fault has different disposal mode, which is as shown in the next table.

Fault Sort	Relevant Disposal	Remark
Level 1 fault	<ul style="list-style-type: none"> • Display fault code • Error relay output action 	Any kind of working condition will not be influenced
Level 2 fault	<ul style="list-style-type: none"> • Display fault code • Error relay output action • Stop at the nearest landing when in distance control, then stop running • Stop running at once in other work condition 	After stop, the system will close off output at once, and close brake
Level 3 fault	<ul style="list-style-type: none"> • Display fault code • Error relay output action • The system blank off output at once, close brake and stop running 	Forbid running
Level 4 fault	<ul style="list-style-type: none"> • Display fault code • Error relay output action • Forbiden fast running • Allow slow running 	Forbid fast running

3.2 Fault Code Description

The fault's display code, cause, countermeasure and sort are seen in Table 3-3.

The keypad displays five data: E+ Fault code

The MCB's small keypad displays three data: E+ Fault code

3.3 Processing Failure

Fault		Fault Reasons	Countermeasure	Sort
Lu Lu	DC bus undervoltage	1: Power-on initial state, power-down end state 2: Input voltage is too low 3: Nonstandard wiring leads to undervoltage 4: Model setting fault	1: Normal power-on or power-down, normal 2: Check input power voltage 3: Check wiring, regulate wiring 4: Set the correct model (Y00.01)	3
E0001 E01	Controller output Acc. overcurrent	1: Main circuit output grounding 2: Main circuit short circuit 3: The motor has not done the parameter self-tuning 4: Load is too heavy 5: Encoder signal is wrong 6: Encoder signal interference is serious 7: Acc. curve is too steep	1: Check the main circuit side whether ground is short-circuited, and output phase is short-circuited 2: Check whether the power wiring is damaged and wiring is solid 3: Check whether the motor internal exists short circuits or shorted to ground 4: Output side contactor is abnormal	3
E0002 E02	Controller output Dec. overcurrent	1: Main circuit output is grounding 2: Main circuit output short-circuited 3: The motor has not done the parameter auto-tuning 4: Load is too heavy 5: encoder signal is wrong 6: Encoder signal interference is serious 7: Dec curve is too steep	5: Whether shorting motor stator contactor causes MONT75 output shorted-circuited 6: Set the correct motor parameters 7: Restart the motor parameter auto-tuning (group F07 or F10) 8: Check the brake, ensure the brake is normal 9: Check the mechanical, ensure it is not stuck	3
E0003 E03	Controller output constant speed is overcurrent	1: Main circuit output is grounding 2: Main circuit output short-circuited 3: The motor has not done the parameter auto-tuning 4: Load is too heavy 5: Encoder signal is wrong 6: Encoder signal interference is serious	10: Check whether the elevator balance coefficient is correct 11: Check whether the encoder wiring is reliable 12: Set the correct group F11 13: Check whether the encoder is installed reliable 14: Encoder wire should be independent through the pipe, trace distance shouldn't be too long, shielding cable is single end ground 15: Set the appropriate Acc. and Dec. curve (group F03)	3

Fault		Fault Reasons	Countermeasure	Sort
E0004 E04	DC bus voltage Acc overvoltage	1: Input voltage is too high 2: Acc curve is too steep 3: Brake resistor is too large 4: Brake unit is abnormal 5: Regenerative unit is abnormal	1: Adjust the input voltage, check D01.06 (bus voltage), ensure it is normal 2: Check the balance coefficient 3: Select the appropriate brake resistor 4: When connect external brake unit or regenerative unit, check related equipments	3
E0005 E05	DC bus Dec overvoltage	1: Input voltage is too high 2: Acc curve is too steep 3: Brake resistor is too large 4: Brake unit is abnormal 5: Regenerative unit is abnormal		3
E0006 E06	DC bus constant speed overvoltage	1: Input voltage is too high 2: Brake resistor is too large 3: Brake unit is abnormal 4: Regenerative unit is abnormal		3
E0007 E07	Static current is too high	When elevator stops, detected current > allowable static current (F09.05)	1: Check there is no feedback load into the inverter output terminals, 2: Add F09.05 value 3: Set F09.05 = 0 to shield the fault	3
E0008 E08	Power module fault	1: Output between phases short-circuited or to ground short-circuited 2: Motor wiring is too long 3: Operating environment 4: Power module damaged	1: Check the wiring, regulate the wiring 2: Install the reactor or filter 3: Check the fan and ventilation duct, ensure they work normally 4: Contact the supplier for repairing	3
E0009 E09	Heatsink overheated	1: Ambient temperature exceeds the specifications 2: The controller external ventilation is adverse 3: Fan is faulty 4: Temperature detection circuit is faulty	1: Derated for using and increase power 2: Rectify controller external ventilation 3: Replace the fan 4: Search for technical support	3
E0010 E10	Brake unit fault	Brake circuit is faulty	Search for technical support	3
E0011 E11	CPU fault	CPU is faulty	1: Power off completely then power on. and observe 2: Search for technical support	3
E0012 E12	Parameter auto-tuning fault	1: Parameter auto-tuning timeout	1: Check the motor wiring 2: Set correct group F07 or F10 (motor parameter)	3

Fault		Fault Reasons	Countermeasure	Sort
		2: Over current at parameter auto-tuning 3: Under the distance control (F00.07 = 1) doing Syn. motor rotating auto-tuning (F10.10 = 2) 4: When Syn. motor doing static auto-tuning, detection current is too little	3: Set F00.07 = 0 (keypad control), and then doing the Syn. motor rotating auto-tuning 4: Decrease F10.02 (motor current) value, then doing Syn. motor static auto-tuning, when finished restore the F10.02 value	
E0013 E13	Soft start	1: Contactor fault 2: Control circuit fault	1: Replace the contactor 2: Seek for technical support 3: Set F16.05 Bit11 = 1, shield the fault	3
E0014 E14	Current detection circuit fault	1: Current detection circuit is damaged 2: Syn. motor is out of control	1: Please contact the supplier for repairing 2: Check the brake signal	3
E0015 E15	Lack of input	Foe three-phase input controller, three-phase input power phase lost	1: Check three-phase input power 2: Check F17.00 and F17.01	3
E0016 E16	Lack of output	1: Controller three-phase ouput broken or loss of phase 2: Controller has serious imbalance in three-phase load	1: Check the wiring between controller and motor, confirm the wiring is correct 2: Check th motor 3: CheckF17.02 and F17.03	3
E0017 E17	Controller overloaded	1: Brake circuit is abnormal 2: Load is excessive 3: Encoder feedback signal is abnormal 4: Parameter of motor faults 5: Check motor power line	1: Check the brake circuit 2: Reduce the load 3: Check the encoder feedback signal 4: Check the motor parameter, and restart parameter auto-tuning (group F07 or F10) 5: Check the power line	3
E0018 E18	Excessive speed deviation	1: Brake contactor faults or running contactor faults 2: Encoder pulse number setting faults 3: Excessive deviation of detection value and time setting is improper 4: Controller output torque is not enough	1: Check the brake contactor or running contactor 2: Set appropriate F11.01 (encoder pulse number) 3: Set correct F04.11 (detected value), F04.12 (time) 4: Select larger capacity controller 5: Set correct group F08 (speed loop PI parameter)	3

Fault		Fault Reasons	Countermeasure	Sort
		5: Speed loop PI parameter setting is improper 6: Encoder signal is wrong 7: Motor parameter is wrong 8: F10.12 is faulty	6: Check encoder wiring and installation, ensure it is reliable 7: Check motor parameter 8: Restart parameter auto-tuning	
E0019 E19	Motor overloaded	1: Brake circuit is abnormal 2: Motor overload protection coefficient 3: Load is too heavy	1: Check the brake circuit 2: Set appropriate F17.04 (motor overload protection coefficient) 3: Reduce the load	2
E0020 E20	Motor overheated	1: Motor is overheated 2: Motor overheating input signal acts 3: Motor parameter setting is wrong	1: Reduce the load 2: Detect the overheating detection input terminal signal, ensure it is correct 3: Set correct group F07 or F10 (motor parameter)	2
E0021 E21	MCB EEPROM writing or reading error	MCU EEPROM storage circuit occurs fault	Contact supplier for repairing	3
E0022 E22	Keypad EEPROM writing or reading error	Keypad EEPROM storage circuit occurs fault	1: Replace the keypad 2: Contact supplier for repairing 3: After the keypad is reset manually, it can continue to be used normally (except download or upload parameters)	1
E0023 E23	Parameter setting error	1: At Asyn. motor doing parameter auto-tuning, Parameter self-tuning under control of non-keypad 2: Asyn. motor select ABZ encoder 3: At Asyn. motor parameter auto-tuning, select keypad control 4: Motor current is zero 5: Asyn. motor no load current > motor rated current 6: Distance control ascend speed (F04.02) > running curve maximum speed (F19.07 - F19.11)	1: At Asyn. motor parameter auto-tuning, set F00.07 = 0 (keypad control) 2: for Syn. motor, set F11.00 = 2 (UVW encoder card) or 3 (SINCOS encoder card) 3: At Syn. motor parameter auto-tuning, set F00.07 = 1 (distance control) 4: Set correct F07.02 or F10.03 (motor current) 5: Set correct F07.11 (Asyn. motor) 6: Reset F04.02 7: Reset F21.07 - F21.09 (service floor)	3

Fault		Fault Reasons	Countermeasure	Sort
		7: $0.000\text{m/s} < F19.07 - F19.11 < 0.100\text{m/s}$ 8: Set the fire base station, locking base station, and idle base station as non-service layer 9: Set the corresopnsed door machine service floor of locking station base, firefighting base station, and idle base station as on-service	8: Set F22.01 - F22.06 (door machine service) permit servicing	
E0024 E24	Input line voltage detection fault	Input bus voltage is normal, line voltage detection circuit is abnormal	1: Power-off treatment 2: Contact the supplier for repairing	1
E0030 E30	Encoder reversal	1: Given speed direction differs from actual feedback direction 2: Load is too heavy 3: Controller output torque is not enough 4: Brake circuit is abnormal 5: Running contactor is abnormal 6: Output line disconnects or lacks of phase	1: When adjusting elevator, reverse F11.02 (encoder rotating direction), when running normally, do not modify F11.02 2: Reduce the load 3: Select larger capacity controller 4: Check the brake circuit 5: Check the run contactor 6: Check the resistor between three-phase, confirm they are coherent	3
E0031 E31	Encoder disconnection	1: Encoder has no input signal 2: Brake circuit abnormal 3: Output power line disconnects or lacks of phase	1: Check the encoder wiring and installation, confirm it is reliable 2: Check the brake circuit 3: Check the resistor between three-phase, confirm they are coherent	3
E0032 E32	Motor overspeed	1: Encoder pulse number setting is wrong 2: Controller output is not enough 3: Speed loop parameter setting is improper 4: Encoder signal is wrong 5: F10.12 is wrong 6: Motor parameter is faulty	1: Set appropriate F11.01 (encoder pulse number) 2: Select larger capacity controller 3: Set correct group F08 (speed loop PI parameter) 4: Check the encoder wiring and installation, confirm it is reliable 5: Restart the parameter auto-tuning 6: Check the motor parameter	3

Fault		Fault Reasons	Countermeasure	Sort
E0033 E33	ABZencoder Z signal lost	1: Wiring problem 2: Jamming is so serious	Check the wiring	3
E0034 E34	UVW encoder UVW fault	UVW encoder fan zone is certainly wrong	Check UVW wiring, confirm the wiring is correct	3
E0035 E35	Sincos encoder CD fault	1: Encoder is faulty 2: Encoder disconnects	1: Check the encoder 2: Check the wiring of encoder C phase and Dphase	3
E0036 E36	Sincos encoder CD fault	1: Speed curve setting is improper 2: Acc. and Dec. setting is improper	1: Set appropriate F19.07 - F19.11 (speed curve) 2: Set appropriate F03.00 - F03.05 (Acc. and Dec. curve parameter)	3
E0037 E37	Abnormal control board logic	MCB logic is abnormal	Please contact the supplier for replacing MCB	3
E0038 E38	Upforce Dec switch disconnect- tion	When elevator is on the top floor, Upforce Dec. switch disconnects	1: Check the upforce Dec. switch 2: Restart the shaft self-tuning 3: Check the leveling switch signal	3
E0039 E39	Downforce Dec switch disconnect- tion	When elevator is on 1 st floor, downforce Dec. switch disconnects	1: Check the downforce Dec. switch 2: Restart the shaft self-tuning 3: Check the leveling switch signal	3
E0040 E40	Elevator running timeout	Within the tiem of F23.02, leveling signal do not change	1: Elcvtor speed is too low or the height of floor is too high 2: Leveling signal is abnormal 3: Wire rope slipped	3
E0041 E41	Safety circuit disconnect- tion	Safety circuit signal disconnects	1: Check the state of all the switches in safety circuit 2: Check the supply circuit of safety circuit 3: Check safety circuit contactor signal 4: Check the features of safety circuit feedback contactor signal (NO or NC)	3
E0042 E42	Door lock disconnectio n during running	When elevator is running, door lock signal disconnects	1: Check the hall door lock and car door lock, confirm the contact is normal	3

Fault		Fault Reasons	Countermeasure	Sort
			2: Check door lock contactor action, confirm it is normal 3: Check door lock contactor feedback contact feature (NO or NC) 4: Check the door lock supply circuit 5: If equipped with advanced door open module (MT70-AOB-A), please check the corresponding signal	
E0043 E43	Uplimit signal disconnection during running	1: When elevator is going up, uplimit signal disconnects 2: Encoder signal interference makes the elevator wrong	1: Check the uplimit switch, confirm the contact is normal 2: Check the uplimit signal feature (NO or NC) 3: The uplimit switch is installed on the low side, when elevator runs to top floor, the uplimit switch should act 4: Check the encoder wiring and installation, confirm it is reliable	3
E0044 E44	downlimit signal disconnection during running	1: When elevator is going down, downlimit signal disconnects 2: Encoder signal interference makes the elevator wrong	1: Check the downlimit switch, confirm the contact is normal 2: Check the downlimit signal feature (NO or NC) 3: The downlimit switch is installed on the high side, when elevator runs to bottom floor, the downlimit switch should act 4: Check the encoder wiring and installation, confirm it is reliable	3
E0045 E45	Up and down force Dec. switch disconnection at the same time	Up and down force Dec. switch disconnect at the same time	1: Check the up and down force Dec. switch, confirm it is normal 2: Check the up and down force Dec. switch (NO or NC) 3: Set F26.12 Bit4 = 1	3
E0046 E46	Releveling abnormal	1: Elevator actual speed > releveling speed + 0.050m/s 2: When elevator is releveling, elevator is not on leveling zone	1: Check the encoder signal 2: Check the leveling signal 3: Check the advanced door open module	3

Fault		Fault Reasons	Countermeasure	Sort
E0047 E47	Lock-door contactor feedback abnormal	Lock-door contactor feedback signal is abnormal	1: Check the lock-door contactor feedback contact signal feature (NO or NC) 2: Check the lock-door contactor action, confirm it is normal 3: Check the lock-door contactor feedback signal 4: Check the advanced door open module	3
E0048 E48	OD fault	The number of the door continuous not opening in place exceeds F22.09	1: Check the door machine 2: Check the CTB, confirm it is normal 3: Check the opening in place signal, confirm it is normal	3
E0049 E49	CD fault	The number of the door continuous not closing in place exceeds F22.09	1: Check the door machine 2: Check the CTB, confirm it is normal 3: Check the closing in place signal, confirm it is normal 4: Check the door lock circuit	3
E0050 E50	Shaft self-learning fault	<p>When starts self-learning, if fulfill with any following condition, it alarms fault:</p> 1. Present floor is not the first floor 2. Self-learning direction is not up 3. Down force Dec signal is invalid 4. Syn.motor initial angle is 0 5. Up limit signal is valid 6. When the total floor is 2, down leveling sensor do not get off leveling plate <p>When runs to second floor, if fulfilled with following conditions, alarms fault:</p> The leveling adjustment distance in second floor after self-learning exceeds 50cm	1: Check up and down Dec. switch signal 2: Confirm the actual number of floor is same as F19.01 (setted number of floor) 3: Syn. motor should do parameter auto-tuing 4: Check the motor actual running direction, confirm it is correct 5: Check the leveling plate, confirm the installation is correct 6: Check the leveling switch NO and NC setting, confirm it is correct 7: Check the uplimit and downlimit signal	3

Fault		Fault Reasons	Countermeasure	Sort
		<p>When runs to top floor, if fulfill with any following condition, it alarms fault:</p> <ol style="list-style-type: none"> 1. When up force Dec. 1 is valid and elevator is in door zone, current floor differs from setted highest floor 2. When elevator reaches setted floor and elevator is in door zone, up force Dec. 1 does not act 3. The learned total height exceeds 50cm 4. The learned up and down force Dec. 1 position is 0 5. If set 2 and 3 rank force Dec. switches, the learned corresponding up and down force Dec. position is 0 6. If select several groups force Dec. signal, once do not fulfill the following conditions, it alarms fault: <ul style="list-style-type: none"> • Down force Dec. position 1 < down force Dec. position 2 < down force Dec. position 3 • up force Dec. position 1 > up force Dec. position 2 > up force Dec. position 3 		
E0051 E51	CAN communication fault	CAN communication do not receive the correct data	<ol style="list-style-type: none"> 1: Check the communication cables 2: Check the CTB power supply 3: Check the 24V power supply 4: Check D04.18 (degree of communication interference) 5: Check the matched resistance ensure it is valid 	1
E0052 E52	Hall call communication fault	Hall call communication do not receive the correct data	<ol style="list-style-type: none"> 1: Check the communication cables 2: Check the 24V power supply 3: Check the HCB address, confirm there is no collides 4: Check D04.17 (degree of communication interference) 	1

Fault		Fault Reasons	Countermeasure	Sort
E0053 E53	Door lock short circuit fault	OD arrival signal and lock door closing signal are valid at the same time	1: Check the door lock circuit action confirm it is normal 2: Check door lock contactor feedback, confirm it is normal 3: Check the door machine opening in place signal 4: Set F26.12 Bit3 = 1	3
E0054 E54	Syn. shorting motor stator contactor feedback abnormal	Syn. shorting motor stator contactor feedback is abnormal	1: Check contactor feedback contact and MCB parameter setting, confirm they are consistent (NO or NC) 2: Check the MCB output terminal indicator and contactor action, confirm they are consistent 3: After contactor action, confirm corresponding feedback contact acts, MCB corresponding feedback input point acts 4: Check contactor and MCB input point features, confirm they are consistent 5: Check the contactor coil circuit	3
E0055 E55	Changed floor park fault	When elevator runs automatically, current floor do not receive opening signal	1: Check the door motor opening in place signal 2: Check the door motor mechanical system	1
E0056 E56	Running contactor feedback abnormal	Running contactor feedback is abnormal	1: Check contactor feedback contact and MCB parameter setting, confirm they are consistent (NO or NC) 2: Check the MCB output terminal indicator and contactor action, confirm they are consistent 3: After contactor action, confirm corresponding feedback contact acts, MCB corresponding feedback input point acts 4: Check contactor and MCB input point features, confirm they are consistent 5: Check the contactor coil circuit	3

Fault		Fault Reasons	Countermeasure	Sort
			6: Set F26.17 = 1, fault resets automatically	
E0057 E57	Brake contactor feedback abnormal	1: Brake contactor feedback is abnormal 2: Barke mechanical switch feedback is abnormal 3: Brake forced feedback is abnormal	1: Check contactor feedback contact and MCB parameter setting, confirm they are consistent (NO or NC) 2: Check the MCB output terminal indicator and contactor action, confirm they are consistent 3: After contactor action, confirm corresponding feedback contact acts, MCB corresponding feedback input point acts 4: Check contactor and MCB input point features, confirm they are consistent 5: Check the contactor coil circuit 6: Check barke mechanical switch feedback signal 7: Check barke forced feedback signal 8: Check brake forced feedback contactor coil 9: Set F26.17 = 1, fault resets automatically	3
E0058 E58	Leveling signal abnormal	Leveling and door zone switch adheres or disconnects	1: Check the leveling, and door zone sensor, confirm it works normally 2: Check the vertical and depth of leveling plate installation 3: Check the MCB input signal	3
E0059 E59	Receive OD and CD arrival signals at the same time	Receive door machine OD and CD arrival signals at the same time	1: Check the door machine controller 2: Check OD and CD arrival signal features (NC or NO) 3: At inspection mode, set F26.12 Bit5 = 1, to shield this fault	3
E0060 E60	Forced Dec. distance is too short	Forced Dec. distance is too shor	1: Check up and down forced Dec. 1 switch installation 2: Check F03.12 (forced Dec. speed)	3

Fault		Fault Reasons	Countermeasure	Sort
E0061 E61	Parallel group control communication abnormal	CAN communication did not receive the correct data	1: Check the communication cable 2: Check the parallel parameter setting 3: Check D04.19 (degree of communication interference)	1
E0062 E62	Inspection running overcurrent	At inspection running, current > motor rated current * 110%	1: Reduce the load 2: Set F26.12 Bit1 = 0 3: When Syn. motor is doing auto-tuning, the result angle does not match the actual value, retart the parameter auto-tuning 4: Encoder is abnormal 5: Brake circuit is abnormal	3
E0063 E63	Advanced door open abnormal	1: Speed > advanced door open speed + 0.050m/s 2: Advanced door open running is not in the leveling zone	1: Check the encoder signal 2: Check the leveling signal 3: Check the advanced door open module (MT70-AOB-A)	3
E0065 E65	UCMP fault	1: When lock-door contactor outputs, controller detects that the door zone signal gets invalid from being valid, and door lock signal disconnects, elevator alarms fault, and stop running, lock-door contactor stop outputting 2: When stops, controller detects door zone signal gets invalid from valid, door lock signal disconnects, and if one leveling signal is invalid, elevator alarms fault, and stop running	1: Check the brake, confirm it is normal 2: Check the door zone signal and leveling signal	3
E0066 E66	Brake force auto-checking fault	1: When brake force detection processes, pulse exceeds the setted F04.16 2: When brake force detection processes, detected speed exceeds 0.50m/s	Check the brake, confirm it is normal	3
E0067 E67	Speed regulator contactor	Speed regulator contactor feedback is abnormal	1: Check contactor feedback contact and MCB parameter	3

Fault		Fault Reasons	Countermeasure	Sort
	feedback abnormal		setting, confirm they are consistent (NC or NO) 2: Check the MCB output terminal indicator and contactor action, confirm they are consistent 3: After contactor action, confirm corresponding feedback contact acts, MCB corresponding feedback input point acts 4: Check contactor and MCB input point features, confirm they are consistent 5: Check the contactor coil circuit	
E0068 E68	CIC-B communication abnormal	Communication between MCB and CIC-B is abnormal	1: Check the communication line between MCB and CIC-B 2: Check the CIC-B internal SIM card, confirm the communication is normal	2
E0069 E69	Logic fault	Logic fault	Return to factory	2
E0070 E70	Bottom pit flooded fault	Control system detects the pit flooded protection signal is valid	1: Check the pit flooded switch 2: Check the pit flooded signal NO or NC setting (group F12)	2
E0071 E71	Overload switch fault	At elevator 0 speed starting detected current exceeds F02.07, overload switch do not act	1: Check the overload switch 2: Check F02.07, confirm the setting is appropriate	1
E0072 E72	Car illegal movement fault	When elevator stops, detects the car moves abnormally	1: Check the brake state 2: Adjust the stop order (confirm there is no slide in elevator stopping)	3
E0073 E73	Forbidden fast car alarm	1: Multi-function input terminal do not set forbidden fast car (49/149) 2: Multi-function set bypass input (50/150)	Check external signal	4
E0074 E74	Internal fault	1: Can not do parameter auto-tuning 2: Can not do shaft self-learning	Contact the elevator factory or agent	3

Fault		Fault Reasons	Countermeasure	Sort
E0075 E75	External regenerative unit fault	Multi-function input terminal sets regenerative unit fault input (51/151)	Check the external signal	1
E0076 E76	External UPS fault	Multi-function input terminal sets UPS fault input (52/152)	Check the external signal	1

3.4 Reset Fault

After the fault is solved, perform any of the following operations to reset:

- Press **STOP** key in keypad.
- MONT75 power down completely.
- Parts of faults can reset automatically, as the following form.

Faults		Reset Conditions
E0009	Heatsink overheated fault	After heatsink temperature drops to 50°C, the fault reset automatically
E0020	Motor overheated fault	After motor safety circuit switch recovers, the fault reset automatically
E0041	Safety circuit disconnection fault	After safety circuit is connected, the fault reset automatically
E0042	Door lock disconnection fault	After door lock is connected, the fault reset automatically, or after door zone signal is valid 1s the fault reset automatically
E0051	Car top CAN communication fault	The fault only recorded once at power-on and after communication resumes, the fault will reset automatically
E0052	Hall Modbus communication fault	The fault only recorded once at power-on and after communication resumes, the fault will reset automatically
E0055	Changed floor stop fault	The fault only recorded once at power-on
E0059	OD and CD arrival signals at the same time fault	The fault only recorded once at power-on and if OD/CD arrival signals are not valid at the same time, the fault will reset automatically
E0061	Parallel group control communication abnormal	The fault only recorded once at power-on and after communication resumes, the fault will reset automatically
E0048, E0049, E0055		Can be reset by inspection button
E0001, E0002, E0003, E0008, E0017, E0030, E0031		in order to protect the internal device of the controller, the fault reset needs to be delayed for a period of time
E0070, E0071, E0073		Can reset automatically